




Baumpflege • Baumfällung
Garten- und Landschaftsbau

Kompetenter Partner seit 1961

H. W. Turk GmbH - Industriestraße 5 - 58553 Halver

Operating instructions for TB-lashing strap

Construction



H. W. Turk GmbH
Industriestraße 5
58553 Halver

Telefon
0 23 53 / 91 21-0

Fax
0 23 53 / 91 21-21

Internet
www.turk-baumpflege.de

E-mail
info@turk-baumpflege.de

Assembly

1. Position your panel within the assembly area of the strap.
2. Place the strap around the correct location, put the end of the strap into the buckle and tighten until it fits loosely.
3. Position the strap, it must not be twisted. Ensure that the spacers lie flat against the tree trunk and that the protective tube lies even.
4. Tighten straps sturdily and validate stable fit. Do not tighten excessively because the growth reserves provided by the spacers would be used up otherwise.
5. Put the strap end into the protective tube.

Maintenance

1. The strap gets tightened in process of time due to the growth of the tree. Ensure a looser fit after your control so that further growth can be compensated by the strap. Assuming an increase of 2,5 cm per year of the circumference the strap must be controlled after two years. Is the increase more than 2,5 cm per year, the maintenance is necessary earlier. Determine the proper interval by your own observations.
2. Check for: deformed buckle locks, broken tube, damaged seam, irreversibly compressed spacers. Don't use any damaged straps.
3. Compressed spacers need time to regenerate. During this period, you may need a replacement strap for strap rotation.
4. For security reasons, the use of two straps per mounting plate is recommended. When one strap fits looser it can compensate more growth.
5. The temperature range for the use of the straps is -40°C to +100°C. Clean the straps with water exclusively, don't use any chemical substances.
6. Don't exceed the admissible efficacy (250 daN in the circumference).

Caution! (important safety message)

The tightening of the straps might cause injuries such as contusions. During the unfastening of the straps mounted objects might fall down. Secure or rope off the working area.

Further information: www.turk-baumpflege.de – Questions and suggestions: info@turk-baumpflege.de – Updated 03-2013



eingetragen beim Verein
für die Präqualifikation
von Bauunternehmen e.V.
unter der Reg.-Nr. 010.034720



VTA-
Visual Tree Assessment



Ihr Experte für
Garten & Landschaft

